



Electrolux

ultraone™

CONSUMABLES & ACCESSORIES

 www.electrolux.com/shop



Silent Parketto
Ref: ZE115
Part nr: 9001677922



Turbo Brush
Ref: ZE119
Part nr: 9001678003



Delicate Care
Ref: KIT11
Part nr: 9001679597



Clean & Tidy
Ref: KIT12
Part nr: 9001679605



Animal Care
Ref: KIT13
Part nr: 9001679613



Performance Kit
Ref: SRK15
Part nr: 9001688903



s-bag® Ultra Long Performance
Ref: E210S
Part nr: 9001684613
s-bag® Anti-allergy
Ref: E206S
Part nr: 9001684605
s-bag® Anti-odour
Ref: E203S
Part nr: 9001684597
s-bag® Classic Long Performance
Ref: E201S
Part nr: 9001684589



Hygiene Washable
Ref: EFH12W
Part nr: 9001951194
Allergy Plus Washable
Ref: EFS1W
Part nr: 9001677682




Crispy Bamboo
Ref: ESBA
Part nr: 9001677773
Brown Sugar & Fig
Ref: ESFI
Part nr: 9001677781
Tropical Breeze
Ref: ESCO
Part nr: 9001677799
Citrus Burst
Ref: ESMA
Part nr: 9001677807
Evening Rose
Ref: ESRO
Part nr: 9001677765



 supportemea.electrolux.com

 www.electrolux.com

B11450202








*
 Certain models only | Suivant les modèles | بعض الموديلات فقط | Само определени модели | Pouze u některých modelů | Nur bestimmte Modelle | Kun på visse modeller | Ainult kindlad mudelid | Solo algunos modelos | فقط برای بعضی مدلها | Vain tietyt mallit | Ορισμένα μόνο μοντέλα | Samo određeni modeli | Csak egyes típusoknál | Solo per alcuni modelli | Tik tam tikriems modeliams | Tikai noteiktiem modeļiem | Alleen bepaalde modellen | Kun enkelte modeller | Tylko niektóre modele | Solo alguns modelos | Doar pentru anumite modele | Только отдельные модели | Bara vissa modeller | Le določeni modeli | Len určité modely | Само код одређених модела | Yalnızca bazı modellerde | Залежно від моделі



5x

=
1x

24h



electrolux.com/shop

Ref: EF54
 9000843053

Ref: EFH12W
 9001951194

Ref: EFS1W
 9001677682